



Quantum® Hardcoated Polycarbonate  
 Windscreen: Z2430 and Z2432 for F800S  
 Z2431 for F800ST

**Read these instructions carefully and thoroughly before beginning work.**

**CONTENTS OF KITS**

Item	Description	Qty.
1	Windscreen	1



**Tools Required:**  
 T25 Torx Driver

**INSTALLATION**

1. Remove the three stock screws and washers. **(T25 Torx Driver)**
2. Remove the stock windscreen.
3. Hold the ZTechnik windscreen in place and starting at the center location, re-install stock washers and screws. **Figure 1.**
4. Tighten all fasteners firmly.



Figure 1.

**MAINTENANCE**

To clean the screen, wash with a clean soft cloth, plenty of warm water and, if necessary, a non-abrasive soap such as dishwashing liquid. Flannel or soft chamois make good cleaning cloths.